



## SAFETY RULES & REGULATIONS

- Obey ALL Signs
- IANA Registered CDL Required
- No Passengers
- Cell Phone Use in Designated Area Only
- Closed-toed Shoes Required
- Use Headlights and Flashers
- Seatbelts Required
- Turn Off Engines at Gate or When Exiting the Vehicle at All Times
- Remove Zip Ties and Place in Trash
- Ensure Tracks Are Clear Prior to Crossing
- No Pull Through Parking
- Perform Tug Test
- Yield to All Ramp Equipment

Knowledge of CSXIT Rules and Regulations are the responsibility of each individual drayman. Copies of the CSXIT Drayman Safety Handbook, CSXIT Safety Rulebook are available on [www.csxintermodalterminals.com](http://www.csxintermodalterminals.com) or upon request at the terminal.

## KEY ACTIONS FOR SUCCESS

### PRE-ARRIVAL

- Verify CDL credentials
- Register in the IANA/UIIA Intermodal Driver Database – [uiia.org](http://uiia.org)
- Verify billing – [ShipCSX.com](http://ShipCSX.com)
- Review Drayman Safety Brief and Handbook – [csxintermodalterminals.com](http://csxintermodalterminals.com)

### IN-GATE

- Turn off engine
- Present CDL
- Provide Seal and Booking Numbers as applicable
- Prepare for In-Gate Inspection
- Follow directions on J1/Mission Ticket or as provided by terminal personnel

### OUT-GATE

- Provide CDL and Seal/Equipment Numbers if requested

### ROADABILITY

- All bad order equipment will be directed to Roadability

### DRAYMAN ASSISTANCE

- Draymen who require assistance will park in the Driver Assistance area and report to the Driver Assistance window

## CONTACT INFORMATION

Check billing, storage and container locations on [ShipCSX.com](http://ShipCSX.com)

For more information, call 800-542-2754, option 2 to speak with a Customer Service Representative.

**CSX** INTERMODAL  
TERMINALS

[csxintermodalterminals.com](http://csxintermodalterminals.com)

6201 Tonnelle Ave | North Bergen, NJ 07047


# NORTH BERGEN DRAYMAN GUIDE



**CSX** INTERMODAL  
TERMINALS

# NORTH BERGEN, NJ

6201 Tonnelle Avenue



## TERMINAL-SPECIFIC PROCESSES

### SAFETY RULES

- Speed limit is 5 mph at all in and out-gate lanes
- Draymen must stop at security to verify gate ticket and seal information

### IN-GATE

- When in-gating a unit, draymen should park tractor under the Gate Inspection Canopy then go inside and speak with a clerk to receive a gate inspection and ticket

### LIVE LIFT PROCESS

- Draymen are to remain in their cabs at all times during live lifting
- Hours for live lift are 0800-1700

### OUT-GATE ROADABILITY

- Draymen will use the phone in the silver kiosk booth located in the out-gate lane to connect with a clerk who will verify unit number, seal and other info so that a gate ticket can be printed in the kiosk

### DRAYMAN ASSISTANCE/ COMMUNICATION

- Security will convey all necessary information