

SPEED LIMIT

15

MPH*
*Unless otherwise posted

SAFETY RULES & REGULATIONS

- PPE required at all times: Protective Eye Glasses; CL2 Reflective Vest; Closed-toe Shoes
- Obey all terminal signs
- IANA-registered CDL required
- No passengers
- Park vehicle before using electronic devices
- Use headlights and emergency flashers
- Seatbelts required
- Turn off engine when exiting vehicle
- Ensure tracks are clear prior to crossing
- No pull-through parking
- No backing up in lanes
- Perform tug test
- Yield to all ramp equipment
- Dispose of all trash prior to arrival
- Report all damage incidents to terminal

KEY ACTIONS FOR SUCCESS

PRE-ARRIVAL – FIRST TIME

- Verify CDL credentials
- Register in the IANA/UIIA Intermodal Driver Database – uiia.org
- Download the ShipCSX app from Google Play or the Apple Store and verify billing
- Access the XGate app and plan all in-gate/out-gate moves

PRE-ARRIVAL – ONGOING

- Verify billing in ShipCSX.com
- Ensure information integrity

ARRIVAL

CAUTION: Enter through the in-gate portal no faster than 5 MPH

XGATE

- XGate mobile applications users only
- Have in-gate mission code ready to scan
- After scanning in-gate QR code, follow mission as directed
- For assistance, use the phone located inside the Driver Assistance area to be directly connected with a terminal representative

SSK IN-GATE

- Ensure information integrity
- Enter CDL, Container Number, Chassis, Seal and Booking Numbers
- Press “NO” on Keep Chassis Prompt
- Follow directions on J1/Mission Ticket or as provided by kiosk
- Retain J1/Mission Ticket for out-gate
- For assistance, use the phone located inside the Driver Assistance area to be directly connected with a terminal representative

ROADABILITY

- Drivers with equipment issues should proceed to roadability area

DEPARTURE

XGATE

- Must use XGate on out-gate if used for in-gate
- Wait for driver ahead to clear
- Enter XGate portal at 5 mph, maintain constant and consistent speed
- Scan out-gate QR code
- For assistance, use the phone located inside the Driver Assistance area to be directly connected with a terminal representative

SSK OUT-GATE

- Must use SSK on out-gate if used for in-gate
- Travel in designated SSK lane
- Verify and have Container, Chassis, Seal, Pickup and Booking Numbers
- For assistance, use the phone located inside the Driver Assistance area to be directly connected with a terminal representative

ADDITIONAL RESOURCES

CSXINTERMODALTERMINALS.COM

XGate registration instructions, user guide and FAQs



Scan QR Code to download the XGate app

Drayman are required to comply with all safety rules in the **Drayman Safety Rulebook**

Review the **Drayman Safety Brief** for rules and policies to operate safely on a CSX intermodal facility

Knowledge of CSX Intermodal Terminal rules are the responsibility of each individual drayman

SHIPCSX.COM

Check billing, storage, reservation information and container locations

CSX INTERMODAL
TERMINALS

700 Fish House Road | Kearny, NJ 07032

KEARNY


DRAYMAN GUIDE



CSX INTERMODAL
TERMINALS

KEARNY, NJ

700 Fish House Road
Kearny, NJ 07032



TERMINAL-SPECIFIC PROCESSES

KEARNY, NJ

OPERATING PROCESS

- Obey all posted speed limit and traffic signs.
- Ramp equipment has right-of-way.
- Park in area indicated on app or ticket.
- Bolster should be even with yellow line.
- Draymen must remain in their vehicles while receiving service at Roadability.
- All units require billing except for empty CSXUs and UMXUs.
- Equipment will be refused if the door cams are not locked in the container.
- Bad orders requiring a live lift must be approved by Roadability.
- All Roadability travel lanes are one way heading west.

IN-GATE

- Use Drive-up or Walk-up kiosks to process mission.
- For severely damaged equipment, go directly to Roadability.
- Remove and properly dispose of zip ties.

LIVE LIFT PROCESS

- Lift tickets are required for chassis flips.
- Live lifts are performed on east end of Track E unless directed otherwise.
- Draymen must ensure all pins/twist locks are unlocked and open prior to lift in the transfer spot (TTR TS).
- If draymen are getting their container mounted, they must ensure the pins are pulled in the open position.
- Draymen are required to set the brake before exiting the cab and stand in front of the truck on the driver side in view of the operator while cranes perform a live lift.

OUT-GATE

- Using the XGate app, draymen are responsible for verifying they have the correct units.
- Out-gate portal uses cameras to verify unit numbers.
- Do NOT back out of the out-gate lane.

DRIVER ASSISTANCE

- For assistance, please call 973-274-2400.
- Driver Assistance is open 24 hours. Most issues can be handled over the phone or through the talk-back system in Lane 1.
- Location inquiries and reservation information is available using the talk-back system in Lane 1.