



## SAFETY RULES & REGULATIONS

- Obey ALL Signs
- IANA Registered CDL Required
- No Passengers
- Cell Phone Use in Designated Area Only
- Closed-toed Shoes Required
- Use Headlights and Flashers
- Seatbelts Required
- Turn Off Engines at Gate or When Exiting the Vehicle at All Times
- Remove Zip Ties and Place in Trash
- Ensure Tracks Are Clear Prior to Crossing
- No Pull Through Parking
- Perform Tug Test
- Yield to All Ramp Equipment

Knowledge of CSXIT Rules and Regulations are the responsibility of each individual drayman. Copies of the CSXIT Drayman Safety Handbook, CSXIT Safety Rulebook are available on [www.csxintermodalterminals.com](http://www.csxintermodalterminals.com) or upon request at the terminal.

## KEY ACTIONS FOR SUCCESS

### PRE-ARRIVAL

- Verify CDL credentials
- Register in the IANA/UIIA Intermodal Driver Database – [uiia.org](http://uiia.org)
- Verify billing – [ShipCSX.com](http://ShipCSX.com)
- Review Drayman Safety Brief and Handbook – [csxintermodalterminals.com](http://csxintermodalterminals.com)

### IN-GATE

- Turn off engine
- Present CDL
- Provide Seal and Booking Numbers as applicable
- Prepare for In-Gate Inspection
- Follow directions on J1/Mission Ticket or as provided by terminal personnel

### OUT-GATE

- Provide CDL and Seal/Equipment Numbers if requested

### ROADABILITY

- All bad order equipment will be directed to Roadability

### DRAYMAN ASSISTANCE

- Draymen who require assistance will park in the Driver Assistance area and report to the Driver Assistance window

## CONTACT INFORMATION

Check billing, storage and container locations on [ShipCSX.com](http://ShipCSX.com)

For more information, call 800-542-2754, option 2 to speak with a Customer Service Representative.

**CSX** INTERMODAL  
TERMINALS

[csxintermodalterminals.com](http://csxintermodalterminals.com)

700 Fish House Road | Kearny, NJ 07032


# KEARNY DRAYMAN GUIDE



**CSX** INTERMODAL  
TERMINALS

# KEARNY, NJ

700 Fish House Road



## TERMINAL-SPECIFIC PROCESSES

### SAFETY RULES

- The terminal speed limit is 5 MPH from the street through the main gate areas
- The Industrial Track (parallel to track 1) is a live track with very tight clearance; use caution

### IN-GATE

- In-gates are only processed at the main gate
- Lane 1 is designated for bobtails only

### LIVE LIFT PROCESS

- Draymen are to remain in their cabs at all times during live lifts
- Lift tickets are required for chassis flips
- Live lifts are performed on east end of Track E unless directed otherwise

### OUT-GATE ROADABILITY

- The back gate is for out-gates only between 0600-1000 weekdays, while the main gate is open 24 hours

- Drayman are to push button for service at the main gate talkback system in order to process outbound equipment
- All roadability travel lanes are one way heading west

### DRAYMAN ASSISTANCE/ COMMUNICATION

- For assistance please call 973-274-2400

- The Driver Assistance window is open 24 hours, however most issues can be processed over the phone or through the talkback systems more efficiently
- All location inquiries and reservation information can be obtained at the talk-backs in the bobtail lane or Lane 1