

SPEED LIMIT

20 MPH*
*5 MPH in the gate area

SAFETY RULES AND REGULATIONS

- Obey all terminal signs
- IANA-registered CDL required
- No passengers
- Cell phone use in designated area only
- Wear reflective vests, safety glasses and closed-toed shoes
- Use headlights and emergency flashers
- Seatbelts required
- Turn off engine when exiting vehicle or at SSK processing gate
- Remove zip ties and place in trash; do not litter terminal with zip ties
- Ensure tracks are clear prior to crossing
- No pull-through parking
- Perform tug test
- Yield to all ramp equipment
- Dispose of all trash prior to arrival

KEY ACTIONS FOR SUCCESS

PRE-ARRIVAL – FIRST TIME

- Register in the IANA/UIIA Intermodal Driver Database – uiia.org
- Download the ShipCSX app from Google Play or the Apple Store
- Access the XGate home page and plan an in-gate move

PRE-ARRIVAL – ONGOING

- Verify billing in ShipCSX.com
- Plan all future moves from XGate home page

ARRIVAL

CAUTION: Enter through the in-gate portal no faster than 5 MPH

XGATE LANE

- XGate mobile applications users only
- Have in-gate mission code ready to scan
- After scanning in-gate QR code, follow mission as directed
- For assistance, call posted driver assist number on kiosk

SSK IN-GATE

- Turn off engine
- Enter CDL, Container Number, Chassis, Seal and Booking Numbers
- Follow directions on J1/Mission Ticket or as provided by kiosk
- Retain J1/Mission Ticket for out-gate
- For assistance, call posted driver assist number on kiosk

ROADABILITY

- Drivers with equipment issues should proceed to roadability area

DEPARTURE

XGATE

- Wait for driver ahead to clear
- Enter XGate portal at 5 mph, maintain constant and consistent speed
- Scan out-gate QR code
- For assistance, call posted driver assist number on kiosk

SSK OUT-GATE

- Travel in designated SSK lane
- Please have Container, Chassis, Seal, Pickup and Booking Numbers
- For assistance, call posted driver assist number on kiosk

ADDITIONAL RESOURCES

CSXINTERMODALTERMINALS.COM

XGate registration instructions, user guide and FAQs

Drayman are required to comply with all safety rules in the **Drayman Safety Rulebook**

Review the **Drayman Safety Brief** for rules and policies to operate safely on a CSX intermodal facility

Knowledge of CSX Intermodal Terminal rules are the responsibility of each individual drayman

SHIPCSX.COM

Check billing, storage, reservation information and container locations



6700 McLarin Road | Fairburn, GA 30213


FAIRBURN

DRAYMAN GUIDE



FAIRBURN, GA

6700 McLarin Road
Fairburn, GA 30213



TERMINAL-SPECIFIC PROCESSES

FAIRBURN, GA

OPERATING PROCESS

- Draymen who fail to follow the mission ticket received at the gate or Drivers Assistance will not be serviced and will experience prolonged long wait times.
- If the assigned wheeled parking location on mission ticket is occupied, draymen should park their container in another location and provide the new location to either the Ramp personnel or Drivers Assistance.
- If the assigned TTR TS (transfer spot) is occupied, draymen should either flag down a terminal employee for further assistance or contact Drivers Assistance via the number posted on the SSK & XGate kiosks.
- Zero tolerance for cell phone and blue tooth usage in the TTR TS (transfer spot).
- After your container has been mounted, all pins/twist locks need to be in the locked position and zip ties secured before proceeding to the out-gate.

IN-GATE

- There is no bobtail lane and every drayman needs a mission ticket to access the terminal.

LIVE LIFT PROCESS

- Draymen must ensure that all 4 pins/twist locks are unlocked and open prior to their container lift in the TTR TS (transfer spot).
- If draymen are getting their container mounted, they must ensure the pins are pulled in the open position.
- Draymen are required to exit the cab and stand in the driver safety box while cranes are performing a live lift.

OUT-GATE ROADABILITY

- Draymen must remain in their cabs during the out-gate process, including during service repair.
- Draymen are responsible for verifying they have the correct container prior to out-gate.

DRAYMAN ASSISTANCE

- Draymen who require assistance should contact Driver Assistance via the number posted on the SSK & XGate kiosks or flag a terminal employee for assistance.